

**CONSOLE SHIFT SLIDE  
INSTALL by  
Dicktator**

**Console shift slider is plastic and travels with shift lever when in use. It travels on plastic “rails” designed into cover.**

**Dicktator**

**Remove Console cover using plastic tool or fingers.**



## **CONSOLE SHIFT SLIDE**

### **INSTALL by**

**Console cover held in place with four metal spring clips.**

**Just lift up.**

**Dicktator**

**Place plastic tool on each side if you have trouble removing.**



**CONSOLE SHIFT SLIDE  
INSTALL by  
Dicktator**

**Shift lever is held in place with torque  
screw on the back side on shifter  
toward dash**

**Dicktator**

**Shift lever torque screw #15.**



## **CONSOLE SHIFT SLIDE**

**INSTALL by**

**This is picture after removal.**

**CONSOLE SHIFT SLIDE  
INSTALL by**

**Dicktator**

**Torque # 15**





## CONSOLE SHIFT SLIDE INSTALL by Dicktator

Suggest you move shift lever down  
away from dash to ease removal.

**SET HAND BRAKE!!**

Key in ignition, turn key to on  
position, press brake pedal, press  
shifter button and move shift lever  
down to 3<sup>rd</sup> or 1<sup>st</sup> gear position.

**NOW!** You can removal torque screw  
on shifter lever easily.



**CONSOLE SHIFT SLIDE  
INSTALL by  
Dicktator Shift**

**lever removed.**

**CONSOLE SHIFT SLIDE  
INSTALL by  
Dicktator**

**Shift console cover removed.**

**Black plastic slider extends beyond  
cover.**

**Dicktator**

**Console Shift Slider goes “above”  
tabs at front.**





## **CONSOLE SHIFT SLIDE**

**INSTALL by  
MUST put on tabs or damage could be  
caused to plastic slider.**

**Dicktator**

**Place shift slider, round end, on  
“TOP” of console tabs for proper  
install.**



**CONSOLE SHIFT SLIDE  
INSTALL by  
Dicktator**

**Put Shift Cover and Shift Slider in  
position over shift lever.**

**Move console cover and slider into  
place.**

**Keep shift slider on tabs and you  
move into position.**



**CONSOLE SHIFT SLIDE  
INSTALL by  
Dicktator**

**Front on Shift Cover Console now in place.**

**Leave rear of console cover  
“unsnapped”.**

**Rear of Shift slide now has to be  
positioned for install.**



**CONSOLE SHIFT SLIDE  
INSTALL by  
Dicktator**

**Console Shift Slide goes in front of  
console connector.**

**Has its own slot to keep from  
“rubbing” on console electric  
connector.**



**CONSOLE SHIFT SLIDE  
INSTALL by  
Dicktator**

**Console Shift slider at rear goes into  
its own “slot” to keep slider from  
electric connector.**

**Dicktator**

**Rear Console Shift Slide in place at  
rear.**





## **CONSOLE SHIFT SLIDE**

**INSTALL by**

**Now close rear Console cover and  
“snap” down.**

**Dicktator**

**Check Shift Lever and Console Cover.**

**Done!**

